



REPLACEMENT SHEET



REPLACEMENT SHEET


FUNCTION KEYS AVAILABLE AT EACH LEVEL



SEE FIGURE 20d

SEE FIGURE 20e

FIGURE 20a2



REAL TIME COPIER DISPLAY PANEL MONITORING MODE

- ALL STATUS INDICATORS
- ALL SETUP INDICATORS
- COPY COUNTS
- ERROR CODES
- POP-UP ERROR CODE
- HELP SCREENS

DISPLAY FACTUAL PROFILE OF SPECIFIED COPIER

- MODEL / SERIAL NUMBER
- PHYSICAL LOCATION
- FACILITIES INFORMATION
- INSTALLATION DATE
- LAST SERVICE DATE

DISPLAY HISTORICAL INFO OF SPECIFIED COPIER

- GROUPED BY FAILURE CLASSIFICATIONS

FIGURE 20b

REPLACEMENT SHEET




FIGURE 20c




FIGURE 20d

REPLACEMENT SHEET




FIGURE 20e